

PHILIPS

Air Purifier

AC0510, AC0520
AC0521



Important

Read this user manual carefully before you use the appliance, and save it for future reference.

Danger

- Do not let any liquid or flammable detergent enter the appliance, to avoid electric shock and/or a fire hazard.
- Do not spray any flammable materials such as insecticides or fragrance around the appliance.

Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, or the appliance itself is damaged.
- This appliance can be used by children aged from 8 years and above under supervision.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- The appliance is only to be used with the power supply unit provided with the appliance.
- Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlet.
- Make sure that foreign objects do not fall into the appliance through the air outlet.

Caution

- This appliance is not a substitute for proper ventilation, regular vacuum cleaning, or use of an extractor hood or fan while cooking.
- Always place and use the appliance on a dry, stable, flat and horizontal surface.
- Leave at least 30cm free space around the appliance and leave at least 30cm free space above the appliance.
- Do not sit or stand on the appliance. Do not place anything on top of the appliance.
- Do not place the appliance directly below an air conditioner to prevent condensation from dripping onto the appliance.
- Make sure that all the filters are correctly installed before turning the appliance on.

- Only use the original Philips filter specially intended for this appliance. Do not use any other filter.
- Combustion of the filter may cause irreversible human hazard and/or jeopardize other lives. Do not use the filter as fuel or for similar purpose.
- Avoid knocking against the appliance (the air inlet and outlet in particular) with hard objects.
- Do not insert your fingers or objects into the air outlet or the air inlet to prevent physical injury or malfunctioning of the appliance.
- Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
- Do not use the appliance near gas appliances, heating devices or fireplaces.
- Always unplug the appliance when you want to move, clean appliance, replace the filter or carry out maintenance.
- The appliance is only intended for household use under normal operating conditions.
- Do not use the appliance in wet surroundings or in surroundings with high ambient temperatures, such as the bathroom, toilet, or kitchen.
- The appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a safety device in case of accidents with combustion processes and hazardous chemicals.
- The essential oils are not included with the product. Please purchase and use the essential oils if needed, according your personal preference.
- Do not add substances other than essential oils to the aroma box.
- Read the user manual of essential oils carefully before using the aroma function.
- Check the ingredients information of the essential oil against your known allergies and exclude it from use when necessary.
- Consult and follow your doctor's recommendation before using the essential oil for infants, pregnant women or women in the lactation period or if you have respiratory issues.
- If you feel unwell, experience irritation or discomfort during the use of the essential oil, please discontinue use.

Notices

Electromagnetic fields (EMF)

This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

Recycling

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.


Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

Your air purifier

Congratulations on your purchase, and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.home.id/support.

Product overview



A Control panel

B Aroma box

E Filter (FY0500)

F Adapter (KA0601A-1200500BSS)

6 English


C Air outlet

G Base

D Top unit

H Aroma pads (FY5100)

Controls overview



Control buttons:



Power on/off button



Mode switch button

Long press the button(s) for 5 seconds:



Filter reset

Display panel:



Sleep mode



Medium mode



Turbo mode



Filter cleaning alert



Filter replacement alert


Getting started

Installing the filter


Remove all packaging of the filter before use.

Note: Make sure the air purifier is unplugged from the electrical outlet before installing the filter.

- 1 Turn the appliance upside down.




- 2 Rotate the base anti-clockwise to remove it from the appliance. Pull the filter out from the appliance.



- 3 Remove all packaging materials of the air purification filter.




- 4 Put the filter back into the appliance. Ensure the filter is level and aligned with the base (of the appliance). Reattach the base and rotate it clockwise to fasten the base.



Connecting power

CAUTION: Risk of electric shock! When you unplug the adapter, always pull the plug from the socket. Never pull the cord.



Connect the power adapter to:

- First, the power adapter on the appliance.
- Then, the wall outlet.

Using the air purifier


Turning on and off

Note:


For optimum purification performance, close doors and windows.

Keep curtains away from the air inlet or air outlet.

- 1 Put the adapter of the air purifier into the power socket.



- 2 Press the power button to switch on the air purifier.
 - The air purifier beeps.
 - The air purifier operates in the Medium mode by default.
- 3 Press the power button again to turn off the air purifier.




Note: If the air purifier stays connected to the electrical outlet after turning OFF, the air purifier will operate under the previous settings when turned ON again.


Changing the mode setting

You can press the mode switch button to select the **Sleep mode**, the **Medium mode**, or the **Turbo mode**.


Sleep mode (☾): The air purifier operates quietly at a low speed. After 3 seconds, the screen lights turn off.



Medium mode (↻): In the Medium mode, the air purifier operates on a medium speed.



Turbo mode (⚡): The air purifier operates on the highest speed.



Using the aroma function

The essential oils are not included with the product. Please purchase and use the essential oils if needed.

Read and follow the safety and use instruction of the essential oil carefully before using it.

Make sure the product is disconnected from the power supply before adding essential oils into the aroma box.


Do not use substances other than essential oils.

Check the ingredient information of the essential oil against your known allergies and do not use it if necessary.


Consult and follow your doctor's recommendation before using essential oils for infants, pregnant women, women in the lactation period, or if you have respiratory issues.

If you feel unwell, experience irritation or discomfort during the use of essential oils, please discontinue use.


Do not use the aroma function with essential oils for infants, pregnant women, or women in the lactation period.



- 1 Push to open the aroma box.



- 2 Remove the aroma box and drop in 2-3 drops of essential oils to the supplied aroma pad.



- 3 Put the aroma box back into the appliance.

Cleaning and maintenance

Note:

Always unplug the appliance before you clean it.

Never immerse the appliance in water or any other liquid.

Never use abrasive, aggressive, or flammable cleaning agents such as bleach or alcohol to clean any part of the appliance.

Never use any liquids (including water) to clean the filter.

Do not attempt to clean the air quality sensor with a vacuum cleaner.

Cleaning schedule


Frequency	Cleaning method
When necessary	Wipe the plastic part of the appliance with a soft, dry cloth
	Clean the air outlet cover
 displays on the screen	Clean the surface of the filter

Cleaning the body of the air purifier

Regularly clean the inside and outside of the air purifier to prevent dust from collecting.


- 1 Use a soft, dry cloth to clean both the interior and exterior of the air purifier.
- 2 The air outlet can also be cleaned with a dry, soft cloth.

Cleaning the filter




When the filter cleaning alert  displays on the screen, clean the surface of the filters with a vacuum cleaner.

Note: We recommend people who are allergic to dust, pollen, pets or mold, not to replace filters by themselves or to take protective measures, such as wearing a mask and gloves.




- 1 Switch off the air purifier and unplug from the power socket.


12 English




- 2 Rotate the base anti-clockwise to remove it from the appliance. Pull the filter out from the appliance.



- 3 Clean the surface of the filters with a vacuum cleaner.




- 4 Put the filter back into the appliance. Reattach the base and rotate it clockwise to fasten the base.




- 5 Put the adapter of the air purifier in the power socket.



- 6 Press the  button to switch on the appliance.



- 7** Press and hold the ☺ button for 5 seconds to reset the filter cleaning time.
- After the reset is successful, the filter cleaning alert disappears from the screen.





- 8** Wash your hands thoroughly after cleaning the filters.


Cleaning the aroma pad and box

For effective aromatherapy, the aroma pad should always be cleaned before using a new essential oil blend. Do not mix essential oil blends.

- 1** Push to open the aroma box.



- 2** Remove the aroma pad and rinse the pad and the box under warm, running water.



3 Dry with a clean cloth and place the pad back into the aroma box.

4 Put the aroma box back into the appliance.

Note:

Do not pour liquid cleaners or detergents into the aroma pad or box.

Replacing the filter

Understanding the healthy air protect lock

This air purifier is equipped with a filter replacement indicator to make sure that the air purification filter is in optimal condition when the air purifier is operating. When the filter needs to be replaced, the filter replacement alert  lights up red. If the filter is not replaced in time, the air purifier will stop operating and automatically lock to protect the air quality in the room. Replace the filter as soon as possible.


Replacing the filter

Note:

The filter is not washable or reusable.

Always turn off the air purifier and unplug from the electrical outlet before replacing the filter.

We recommend people who are allergic to dust, pollen, pets or mold, not to replace filters by themselves or to take protective measures, such as wearing a mask and gloves.




When the filter replacement alert  displays on the screen, replace the filter (FY0500).


To purchase a replacement Philips filter, please scan the QR code printed on the filter. If the Philips HomeID shop app is available in your country, you will be directed to the product purchase page automatically after downloading the app. If the Philips HomeID app shop is not supported in your country, please search for filter (FY0500) at your preferred local retailer.

Note:


We recommend people who are allergic to dust, pollen, pets or mold, not to replace filters by themselves or to take protective measures, such as wearing a mask and gloves.




1 Switch off the air purifier and unplug from the power socket.




2 Turn the appliance upside down.




3 Rotate the base anti-clockwise to remove it from the appliance. Pull the filter out from the appliance. Discard the used filter.



4 Remove all packaging materials of the new filter.




- 5 Put the new filter into the appliance. Reattach the base and rotate it clockwise to fasten the base.



- 6 Put the adapter of the air purifier in the power socket.



- 7 Press the  button to switch on the appliance.



- 8 Press and hold the  button for 5 seconds to reset the filter lifetime counter.
- After the reset is successful, the filter replacement alert disappears from the screen.




- 9 Wash your hands thoroughly after replacing the filter.

Note: Do not smell the filter as it has collected pollutants from the air.


Filter reset

You can replace the filters even before filter replacement alert () displays on the screen. After replacing filters, you need to reset the filter lifetime counter manually.


1 Press the  button to turn off the appliance. Unplug the appliance.



2 Make sure the appliance is completely unplugged, and then put the power adapter in the power socket.



3 Within 15 seconds after power on, press and hold the  button for 5 seconds to reset the filter lifetime counter.



Storage

- 1** Turn off the air purifier and unplug from the power socket.
- 2** Clean the air purifier and the surface of the filter (see Chapter "**Cleaning and Maintenance**").
- 3** Let all parts air dry thoroughly before storing.
- 4** Wrap the filter in air tight plastic bags.
- 5** Store the air purifier, filter in a cool, dry location.
- 6** Always thoroughly wash hands after handling filter.

Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Center in your country.

Problem	Possible solution
The appliance does not work properly.	The filter replacement alert has been on continuously but you have not replaced the corresponding filter. As a result, the appliance is now locked. In this case, replace the filter and long press the  button to reset the filter lifetime counter.
The airflow that comes out of the air outlet is significantly weaker than before.	The surface of the filter is dirty. Clean the surface of the filter (see Chapter 'Cleaning and maintenance').
The air quality does not improve, even though the appliance has been operating for a long time.	Check if the packing material is removed from the filter.
	The filter has not been placed in the appliance. Make sure that the filter (FY0500) is properly installed.
	Room size is large or the outdoor air quality is poor.
	For optimum purification performance, please close the doors and windows when operating the air purifier.
	There are indoor pollution resources. For instances, smoking, cooking, incense.
	Filters reach the end of life. Replace the filter with a new one.
The appliance produces a strange smell.	The first few times you use the appliance, it may produce a plastic smell. This is normal. However, if the appliance produces a burnt smell even if removing the filter, contact your Philips dealer or an authorized Philips service center. The filter may produce smell after being used for a while because of the absorption of indoor gases. It's recommended that you reactivate the filter by putting it in direct sunlight for repeated use. If odor still exists, replace the filters.
The appliance is extra loud.	It's normal if the appliance runs at the Turbo mode.
	If there is abnormal sound, contact the Consumer Care Center in your country.
	If anything drops into the air outlet, it may also cause abnormal loud sound. Immediate turn off appliance, turn appliance upside down, to get foreign objectives out of appliance.
The appliance still indicates that I need to replace filter, but I already did.	Perhaps you did not reset the filter lifetime counter. Switch on the appliance. Then press and hold the  button for 5 seconds.
My aroma function doesn't work well (too weak or strong).	Use proper 2-3 drops essential oil.

	Different essential oil may has different perceived intensity.
	It need take sometime to evaporate the smell to whole room.
Error code "E1" displays on the screen.	The motor has malfunctions. Contact the Consumer Care Center in your country.

Warranty and support

Versuni Netherlands B.V., registered at Claude Debussylaan 88, Amsterdam, NL, offers a two-year warranty on this product after the date of purchase (or the date of delivery, if later). This warranty is not valid if a defect is due to incorrect use or poor maintenance. Our warranty does not affect your rights under law as a consumer. For more information, for spare parts, or for invoking the warranty, please visit our website **home.id/warranty**.

Order parts or accessories

If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit **www.home.id/support**.

If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country.

PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Versuni Holding B.V., and Versuni Holding B.V. is the warrantor in relation to this product.

2026 © Versuni Holding B.V.



LOVEAIR

Instrukcja pobrana ze strony loveair.pl



www.home.id